


Optimalt styretryk

Optimum control pressure



(A) Driftstryk (fødetryk)

(B) + Differenstryk
 Δp mellem styretryk [C] og driftstryk [A]

(C) = Optimalt styretryk, der skal indstilles
(lukketryk)

► Hvor mange bar lufttryk (optimalt styretryk) er der brug for, for at lukke slangeventilen?



(A) Operating pressure (line pressure)

(B) + Differential pressure
 Δp between the control pressure [C] and operating pressure [A]

(C) = Optimum control pressure to be set
(closing pressure)

► How much compressed air (control pressure) is required to close the pinch valve?

OPTIMALT STYRETRYK

Driftstryk

+

Differenstryk

|
Retningslinje kunde

|
Typeskilt
(tekn. infoblad
„slange materialer“)

OPTIMUM CONTROL PRESSURE

Operating pressure

+

Differential pressure

|
Customer specification

|
Type plate
(techn. info sheet
sleeve qualities)



Anvisning:

Slangeventilens maksimale styre-/driftstryk findes på typeskiltet hhv. i databladet!



Note:

Please refer to the type plate or article text for the maximum control / operating pressure of the pinch valve!

Ret til tekniske ændringer forbeholdes.

Technical details subject to change without notice.